PARTS LIST

for



GAS DRYER

MODEL RGL4434AW0

▲ W-White, L-Almond



FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS




Whirlpool CORPORATION

Benton Harbor, Michigan.

TOP AND CONSOLE PARTS

For Model: RGL4434AW0



TOP AND CONSOLE PARTS

For Model: RGL4434AW0


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
140.	140.	DESCRIPTION	140.	140.	DESCRIPTION	140.	140.	DESCRIPTION
1	3397545	Panel, Rear Console	14 16	3353145	Screw, Console Top	48	3391823	Timer Knob & Dial
2	693994	Screw, Hex		3396022	White	53	3396293	Bracket, Control
		Washer Head		3396023	Almond	54	3397306	Panel, Control
3	693995	Screw, Hex Head	17	3396028	Wire-Jumper	67	689559	Nut, Push-On (4)
4	3358016	Cap, End (L.H.)			Assembly .	72	690853	Wire, Ground
5	689180	Clip, Retainer	18	94614	Terminal	75	691707	Receptacle,
7	3357998	Cap, End (R.H.)	19	3352167	Knob,			Latching (3–Way)
8	357213	Nut, Push-In (2)			Temperature			(Uses Terminal
10	337448	Screen, Lint			Selector			94614)
11	688150 689310	Cover, Lint Screen White Almond	21 23	3396215 3396220	Timer Assembly, 60 Hz. Harness, Wiring	79	3354281	Switch, Temperature Selector
12	339229	Hinge, R.H.	29	3390646	Screw, 8–18 x 5/16	81	3391829	Knob,
	339230	Hinge, L.H.	39	660936	Switch,			Push-To-Start
13	688983	Screw, 8–18 x 5/8		223000	Push-To-Start 692021 (Alt.)			

LITERATURE AND OPTIONAL PARTS

Illus. Part No. No.	DESCRIPTION	Illus. I	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	
LITERATURE	OPTIONAL PARTS NOT INCLUDED							
LIT3396298 LIT3395325	Use & Care Guide Instructions, Installation	PAINT, TOUC		H-UP (1/2oz.)	PAIN	PAINT, BULK (1 qt.)		
LIT4377013	List, Service Parts		72017 72107	White Almond		799344 978883	White (Uncut) Almond (Uncut)	
	PAINT (13 oz.	•	SURIZED SPRAY					
		3	350930 350956 350938 350941	White Almond Primer, Gray Leveler (Thinner)				

CABINET PARTS

For Model: RGL4434AW0



CABINET PARTS


For Model: RGL4434AW0

Illus	. Part		Illue	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
110.	110.	DEGCINI HON	-140.	110.	DEGCKII HON	· - 140.	110.	DEGORII HOR
	007770	0		000075	Dive	67	004070	Duman Anamahlu
1	697776	Screw, 10–16 x 1/2	29 31	660975 98997	Plug	67	694670	Burner Assembly, 60 Hz.
2	343641 693995	Screw, 10–16 x 1/2	32	694091	Clip, Harness Screw			(Refer To Pages
3		Screw, Hex Head	33	696144				6 & 7 For Further
4	3393657	Restrainer, Belt	35		Strike, Door			
5	690893	Cover, Block		695953	Door, Rear	60	341029	Breakdown)
6	2204075	Plug, Front Panel White	36	348737	Door, Front	68 69	694572	Clamp, Pipe
	3394975				White	69	694572	Kit, Conversion
7	3394976	Almond	27	689485	Almond			(Type 1, 2 & 3
7	347736	Panel, Rear	37	000070	Handle, Door		070040	To Type 4)
8	688160	Screw, 8–15 x 1/2		690270	White		279243	Kit, Conversion
9	691581	Clip, Door Switch		690271	Almond	0.5	CO 40E 4	(Type 1 To Type 3)
10	347207	Switch, Door	38	349462	Seal & Bearing	85	694054	Valve, Gas
11	98129	Screw,	1 40	2222724	Assembly			60 Hz.
40	227400	6–20 x 7/8 (2)	42	3390734	Seal, Door	00	000004	(Complete)
12	337182	Guide, Cable(L.H.)	45	344020	Cord, Power	86	660991	Ignitor
40	337183	Guide, Cable(R.H.)	51	238088	Hinge, Top (2)	0.7	222222	686590 (Alt.)
13	339493	Screw	53	691366	Idler & Pulley	87	3393909	Screw & Washer
14	230131	Cable, Door (2)		000000	Assembly	88	694539	Coil, 60 Hz.
15	3394083	Clip, Front Panel	56	660996	Belt, Drive			(Split)
16	3392100	Foot, Dryer (4)	57	348780	Base, Motor			(3 Terminal)
17	337186	Spring, Door	58	172455	Bolt,		00.45.40	(Pilot Position)
18	0004400	Cabinet		0000007	5/16–18 x 3/4	89	694540	Coil, 60 Hz.
	3394109	White	59	3389627	Pulley, 60 Hz.			(2 Terminal)
40	3394110	Almond	61	3388235	Switch, Motor		004404	(Main)
19	98234	Clip, Ground (2)	62	3391888	Motor, 60 Hz.	90	694421	Screw, Bracket
20	690363	Lock, Front Top (2)			(Pulley Not			Mounting
21		Front Panel			Included With		004500	(8–32 x 1/2)
	0004000	Assembly		000050	Motor)	91	694538	Bracket, Coil
	3394890	White	63	660658	Clamp, Motor (2)	92	694426	Harness, Wiring
00	3394891	Almond			343481 (Alt.)	93	694424	Leak Limiter
23	685203	Clip, Felt Pad		000000	685441 (Alt.)	94	694423	Screw, Regulator
24	690081	Catch, Door	64	690236	Wire, Ground	0.5	004400	Adjustment
25	693994	Screw, Hex Head			(Motor)	95	694422	Spring, Regulator
28	238456	Hinge, Door(R.H.)				96	694510	Clip, Harness
	238460	Hinge, Door(L.H.)				97	239822	Plug, Pipe
			•					

694670 BURNER ASSEMBLY

For Model: RGL4434AW0

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES




694670 BURNER ASSEMBLY

For Model: RGL4434AW0

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus No.		DESCRIPTION
1	694670	Burner Assembly 60 Hz. (Type 1, 2 & 3)
2	600647	(White Rodgers)
2	688617 694298	Tube, Burner Bracket, Ignitor
4	660991	Ignitor
_	000050	686590 (Alt.)
5	686953	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	693986	Base, Burner
8	339527	Screw, 8-32 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419 229742	Type 3 Type 4 (Butane)
	234868	Type 4 (Propane)
10	694054	Valve, 60 Hz.
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz.
		(2 Terminal)
14	694539	(Main) Coil, 60 Hz.
		(Split)
		(3 Terminal)
15	694424	(Pilot Position) Leak Limiter
16	694423	Screw, Regulator
47	004400	Adjustment
17 18	694422 694426	Spring, Regulator Harness, Wiring
10	00 1720	(Complete)
19	694510	Clip, Harness
20 21	239822 233273	Plug, Pipe Pipe, Gas Supply
22	345062	Valve & Union,
		Shut-Off
23	3393767	Pipe, Tail
24 25	233076 341029	Nut, Compression Clamp, Pipe
20	011020	Clamp, 1 ipo
	owing Pa	rts Not Illustrated
- 0110		
	279243	Conversion Kit
		Type (1) Natural to
		Type (3)
	00:	Manufactured
	694572	Conversion Kit (Type 1, 2 & 3)
		to Type (4) L.P.G.

BULKHEAD PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute	15	660036	Thermostat,	41	690997	Ring, Tri
		Assembly			205°F (96°C)	42	347364	Shaft, L.H.
2	343641	Screw, 10-16 x 1/2			338471 (Alt.)	43	339489	Shaft, R.H.
3	98460	Nut, Push-In			341196 (Alt.)	44	3389901	Roller, Support
4	3388703	Washer, Support	16	337445	Support, Heater	46	348197	Washer, Support
5	90767	Screw, 8A x 3/8			Box (2)	47	3359452	Nut, 3/8-16
6	3392519	Fuse, Thermal	17	337450	Collar, Funnel	48	685775	Bulkhead
7	347139	Seal, Lint	18	347389	Funnel, Burner	49	338906	Sensor, Radiant
		Chute	23	695239	Screw, 8-18 x 3/8	62	3394508	Ring, Bearing
8	3387134	Thermostat,	24	696302	Shield, Exhaust	63	97787	Screw, 11-16 x 7/8
		Internal-Bias	25	686889	Pad, Cabinet	66	337449	Seal, Rear Drum
10	694089	Wheel, Blower	26	3392247	Pad, Blower	67	695584	Drum Assembly
11	695081	Housing, Blower			Housing	68	342847	Baffle, Drum
12	337272	Clip	27	3392123	Seal, Blower	69	348945	Bracket, Support
13	687128	Screw, 10-16 x 1/2			Shaft	70	90296	Clip
14	685458	Box, Heater				73	339956	Seal
			I					